Punch



96636058 PUNCH 3 EMERGENCY BATTERY SPARE

Punch

Spare battery for Punch range:

For replacement, please refer to the installation instructions for the luminaire.